

Bandes		Position sur S E L F																			
		0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
3,5						98-80	79-75	70-71	60-71					46-55				36-52	35-48	31-48	30-45
3,7							100-60	84-56	80-55		63-47			56-38		47-37		42-34	41-33	37-32	36-28
3,5								46-95	38-96		33-86			29-76		25-71		22-66		20-60	18-57
3,7							44-93	42-86	38-84					28-64							17-52
7,1					82-47	56-46	44-37	38-33	33-30	30-28		25-25		13-13		15-13	13-11	12-11	11-10		
7,1					32-85	25-73	24-64	21-55		13-47				7-32		6-26		6-22*			
10,1			56-66	37-55		22-37		13-27		9-20	6-16*	5-13*									
10,1					32-65	25-49		16-33		11-21		7-12*									
14,1		75-38	45-38	27-26		12-15		6-7													
14,3		80-42						11-9													
14,1			36-73	23-46	15-37	12-25	3-7*														
14,3			32-75	20-50	18-30	9-26	7-18	4-12	3-6*												
18,1		60-62	27-40	16-20	11-11	6-6															
18,1			17-58	11-35	4-14	3-12															
21,1		44-37		10-12	6-7																
21,3		48-37	16-15	10-10	6-6																
21,1		72-74	44-31	16-20	11-12	5-6															
21,3		67-35	47-26	18-16	12-11	6-4															
24,9		50-49	20-36	10-16	6-8																
24,9		50-40	20-32	9-16	2-6																
28,1		26-40	10-25	3-13																	
28,8		50-61	13-20	6-10																	
28,1		14-48	6-33																		
28,8		15-38	6-27																		
29,5		30-35	20-25	7-5																	
29,5		52-82	47-82	45-84	42-93	40-93															

* trop pointu

Valeurs de réglage des CV sur une échelle allant de 0 à 100 (0 val mini)

Spire n° :	1	4	7	13	18
			80m	80m	80m
		40m	40m	40m	40m
		30m	30m		
Exemple de point de branchement sur la self pour un commutateur	20m	20m	20m		
	17m	17m			
	15m	15m			
	12m				
	10m				